

# Assembly Instructions for THE CAVE™



## THE CAVE™ 4 PERSON TENT

### WARNING:

KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC. THIS TENT MEETS THE FLAMMABILITY REQUIREMENTS OF CPAI-84. THE FABRIC MAY BURN IF LEFT IN CONTINUOUS CONTACT WITH ANY FLAME SOURCE. THE APPLICATION OF ANY FOREIGN SUBSTANCE TO THE TENT FABRIC MAY RENDER THE FLAME-RESISTANT PROPERTIES INEFFECTIVE.


Snugpak LTD  
Waterloo Mills, Howden Road  
Silsden, West Yorkshire  
BD20 0HA, England  
Tel: +44 (0) 1535 654479 Fax: +44 (0) 1535 652503

[www.SNUGPAK.com](http://www.SNUGPAK.com)

Snugpak® products are exclusively distributed in North & South America by:  
**PROFORCE EQUIPMENT, INC.**  
3230 Executive Way - Miramar, FL 33025  
Ph: 305.436.7984 / 800.259.5962  
[www.PROFORCEEQUIPMENT.COM](http://www.PROFORCEEQUIPMENT.COM)

[www.SNUGPAKUSA.com](http://www.SNUGPAKUSA.com)

1



- Take out the Inner Tent/Main Body (Mosquito Netting) and unfold and spread it out.
- Assemble the Pole Sections – Carefully unfold the pole sections and allow them to slide together by inserting one section within another section.
- Insert the poles into the pole sleeve channels. Note the OLIVE Tipped Poles go into the Pole Sleeve Channels with the OLIVE trim edging and the solid BLACK Poles go into the two remaining Pole Sleeve Channels.

2



- Begin to insert the pole ends into the grommet closest to the Inner Tent/Main Body in the corresponding webbing straps. Once all the poles ends are inserted in the grommets the Inner Tent should now stand erect. *Note: the OLIVE Tipped Poles should crisscross as shown in the illustration.*
- The pole channels and poles should intersect for proper form, support and structure. *Note: there is a secondary grommet on the corner webbing straps for different style stakes, if desired.*
- At this stage the Cave can be used as a stand-alone insect shelter, if desired.

3

- Now take out the Fly and unfold and spread it out. Then drape the Fly over the Inner Tent/Main Body matching up the door areas and then connect the two together. *(Note: the two doors of the Cave are the exact same size and there is no difference.)* The Fly and Inner Tent/Main Body are joined together by simply connecting to one another by the Side Release Buckles located at points where the pole ends are inserted into the webbing straps.
- Now take the pole with the GREY Tipped Ends and insert it into the Pole Sleeve Channel on the Fly with the grey trim edging on the double entry side. The GREY Tipped Pole ends should then go into the second grommet on the corner webbing strap of the Main Body/Inner Tent.
- Now take the Ultralight Alloy Stakes and stake out the Inner Tent/Main Body area of the Cave and then after that stake out the vestibule and door areas. Stake out guy ropes as needed for additional support and for increased stability in inclement weather.



### COMPONENTS

- [2] BLACK tipped Black Poles
- [2] OLIVE tipped Black Poles
- [1] GREY tipped Black Pole

[25] Stakes



[1] Inner Tent / Main Body



[1] Fly